Atlas Scientific™
Environmental Robotics

Arduino Mega
EZO-CO2™ Sample Code
Revised 6/2019



After flashing the Arduino with the code below, open the serial monitor and set it to append *carriage return* only and then set the baud rate to *9600*.



Click here to download the sample code